

DESIGN DR		DRAWN BY	DART AEROSPACE LTD HAWKESBURY, ONTARIO, CANADA	
CHECKED		APPROVED	DRAWING NO. D3070 SHE	REV. A ET 1 OF 2
02.09. 1 1			STEP ASSEMBLY, HI LONG	SCALE NTS
Α	02	2.09.11	NEW ISSUE	
Al	02	2.11.13 (P)	110.71 WAS 110.56	



Part No.	Description	QTY -041	QTY -042	
D3070-041	Step Assembly, High Long (LH)	Х		
D3070-042	Step Assembly, High Long (RH)		Х	
			77	
D2622-120	STEP EXTRUSION	1	1	
D3063-1	SUPPORT	1	1	
D3065-041	LEG ASSEMBLY	1	1	
D3066-1	SPACER	2	2	
D3067-1	END PLATE	2	2	
MS20600AD4W4	RIVET	16	16	

GENERAL NOTES:


- 1) -041 SHOWN, FOR -042 INSTALL D3063-1 SUPPORT OPPOSITE SIDE
- 2) WELD PER DART QSI 004
- 3) FINISH: CHEMICAL CONVERSION COAT PER DART QSI 005.4.1
 POWDER COAT ASSEMBLY WHITE (4.3.5.1) PER DART QSI 005 4.3
 BLACK ANTI-SKID PAINT PER DART QSI 005 4.4
- 4) TOLERANCES ARE PER DART QSI 018 UNLESS OTHERWISE NOTED.



0



	DESIGN OF DRAW		DRAWN BY	DART AEROSPACE LTD HAWKESBURY, ONTARIO, CANADA		
)	CHECKED	t	APPROVED	DRAWING NO. SHE	REV. A ET 2 OF 2	
	02.09.11			STEP ASSEMBLY, HI LONG	SCALE 1:20	
	Α	-	2.00.44	NEW IOOUE		



COPYRIGHT ©2002 BY DART AEROSPACE LTD.